



Brink is not responsible for damages directly or indirectly resulting from incorrect assembly, which is understood to mean the use of inappropriate tools, methods of assembly other than those prescribed and the incorrect interpretation of the assembly instructions provided.




© Brink International 2006



USER MANUAL
RETRACTABLE

in.


1.1



1.2





1.4




1.5





out. *out*


2.1




2.2



2.3a




2.3b



2.4



2.5



2.6

